

**NEW!**

# Adjustable Attic Insulation Shield

- The Adjustable Attic Insulation Shield must be installed where the vent enters the attic space in any installation.
- Designed to keep insulation away from the vent and to maintain the mandatory 1" clearance to combustibles.
- Adjustable from 11" to 20"
- Includes base with shield, extension shield and collar



**Choose from the sizes below:**

1604491	4DT-AAIS	4 x 6 5/8 ADJUSTABLE ATTIC INSULATION SHIELD
1605491	5DT-AAIS	5 x 8 ADJUSTABLE ATTIC INSULATION SHIELD

